
## INSTALLATION INSTRUCTIONS



1. PLACE SEAL ON SHAFT. CAUTION: NOTICE POSITION OF GLAND O-RING

- SECURE ZMT BACK PLATE TO PUMP ADAPTOR, AND FINISH ASSEMBLING PUMP.
- 3. AFTER IMPELLER HAS BEEN TIGHTENED ON THE SHAFT, BOLT THE SEAL TO THE BACK PLATE.
- 4. TIGHTEN THE TWO 1/4" SET SCREWS TO THE SHAFT.
- 5. REMOVE THE CLIPS FROM THE SEAL.
- KEEP CLIPS FOR FUTURE USE.
  - 6. THE SEAL IS READY TO GO. START THE PUMP.

## ZERO MAINTENANCE SEALS

ENGINEERED & BUILT BY

TRI-CLOVER PUMP MODELS 216, 218, 328, 4410 JANUARY 1, 1994

PHONE (209) 547 - 1965, FAX (209) 464 - 8140